



4.1TL MOD Instructions

1. Place jumper between E & H
2. Place 5.8uF cap at C5
3. HF Harness needs large faston on ground (White)
4. Replace SL2000 with SL3000 / RDO198-1
5. (OPTIONAL) Replace MW6503 with MW6510

Custom SDA 2B 1987 (Blade/Blade) Schematic

DRAWN BY gimpod ON 11/27/10

!! POLK AUDIO HAS ABSOLUTELY NOTHING TO DO WITH OR HAS ANY RESPONSIBLY FOR THIS SCHEMATIC !!