



4.1TL MOD Instructions

1. Place jumper between E & H
2. Place 5.8uF cap at C5
3. HF Harness needs large faston on ground (White)
4. Replace SL2000 with SL3000 / RD0198-1
5. (OPTIONAL) Replace MW6503 with MW6510

BINDING POST

TWEETER ARRAY 1 X SL2000

STEREO ARRAY

1 X MW6503 or MW6510

DIMENSIONAL ARRAY

1 X MW6511